

# INSTALLATION GUIDE MODEL #: ESPL4-1150e

Linear Series | T8 Class 4FT LED Shop Light



# Questions?

For customer service please call us at 1-888-743-5766 Office Hours: 8:00 a.m. – 5:00 p.m. PST Monday-Friday



#### PLEASE REVIEW THE INSTRUCTIONS AND WARNINGS LISTED BELOW PRIOR TO PROPER INSTALLATION


## **WARNINGS**

- Risk of fire / electrical shock.
- Risk of electric shock disconnect power at source before installation.
- Do not make or alter any open holes in an enclosure of wiring or electrical components during installation.
- Failure to comply with installation instruction could result in personal injury or property damage.
- If fixture or luminaire exhibits abnormal operation (buzzing, flickering, minimal light, etc.), turn off power, remove fixture and contact us. For more information, please visit www.eurilighting.com or call our toll-free number 1-888-743-5766.


### **CAUTIONS**

- Do not look directly at the operating LED Shop Light.
- Do not touch this product with wet hands.
- Do not disassemble, repair or alter fixture.
- · Designed for indoor applications only.
- Suitable for damp locations.
- Do not allow fixture to hang from cord.
- Do not use on dimming circuit.
- . Do not install on radiant-heating ceilings.
- A maximum of 10 units can be connected in any configuration.

# LED SHOP LIGHT INSTALLATION INSTRUCTIONS




Remove your new LED Shop Light from its package and verify that content includes: (4-pcs) Hanging Chains, (8-pcs) "S" Hooks, (2-pcs) Ceiling Hooks, (1-ea) Connecting Wire, (1-ea) Connector & (1-ea) Powercord with plug.



Prior to the installation process, please make sure to TURN OFF all power switches








3a) Install Ceiling Hooks into the ceiling.3b) Attach one "S" Hook onto each Ceiling Hook


3c) Hang one chain from each "S" Hook.



4a) Attach two "S" Hooks to both ends of fixture.

4b) Fold two chains, each into half.

4c) Hook one "S" Hook into center link of each chain.



While supporting unit, attach "S" Hook from one end of the folded chain to the chain hanging from ceiling. Repeat for opposite side.



Connect power cord (labeled "M") into socket (label "M"). Plug power cord into wall outlet and turn-on power. To operate shop light pull down on the Pull-chain on/off switch.

#### Alternative Connection Method #1




Before applying power, repeat steps 1 - 5 for each additional fixture when using the Alternative Connecton Method #1. Use the connector to connect up to a maximum of 10 fixtures.

# Alternative Connection Method #2

Before applying power, repeat steps 1 - 5 for each additional fixture when using the Alternative Connecton Method #2. Use the connecting wire to connect up to a maximum of 10 fixtures.

#### NOTE

To ensure proper operation, use only as marked.



"F" Connection, end with the Pull-chain on/off switch.